



cella berlin



Brotteller
Assiette pain
Ø 16 cm x H 2 cm



1101_10_010	6.25
1101_10_000 glatt/lissé	5.95

Teller flach
Assiette plate
Ø 22 cm x H 2,3 cm



1102_10_010	9.95
1102_10_000 glatt/lissé	9.50

Teller flach
Assiette plate
Ø 25 cm x H 2,5 cm



1103_10_010	12.80
1103_10_000 glatt/lissé	12.50

Teller flach
Assiette plate
Ø 28,5 cm x H 2,8 cm



1105_10_010	14.50
1105_10_000 glatt/lissé	13.50



Platzteller/Platte
Assiette présentation/Plat
Ø 32,5 cm x H 2,4 cm



1106_10_010	19.50
1106_10_000 glatt/lissé	18.50

Pizzateller
Assiette pizza
Ø 34 cm x H 2,5 cm



1107_10_010	22.50
-------------	-------

Teller schmale Fahne
Assiette à bord étroit
Ø 25,5 cm x H 2,7 cm



1104_10_010	13.50
Passend/compatible 5107_10_010	

Cloche
Cloche
Ø 24 cm x H 9,5 cm



5107_10_010	41.00
-------------	-------



Teller tief
Assiette creuse
Ø 23 cm x H 4,3 cm / 21 cl



1108_10_010	11.50
1108_10_000 glatt/lissé	11.50

Teller tief
Assiette creuse
Ø 25,5 cm x H 4,0 cm / 30 cl



1109_10_010	12.80
-------------	-------

Gourmetteller
Assiette gourmet
Ø 27,5 cm x H 3,8 cm



1110_10_010	24.00
-------------	-------

Gourmetteller
Assiette gourmet
Ø 30,5 cm x H 6 cm / 173 cl



2106_10_010	29.50
-------------	-------



Olivenschale
Bol ovale
15 x 6 cm x H 1,6 cm



1201_10_010

8.75

Coupeschale oval
Bol ovale
30 x 10,5 cm x H 3,7 cm



1202_10_010

24.50

Hors d'Œuvre Schale
Bol ovale
30,5 x 14 cm x H 5 cm



1203_10_010

26.50

Tablett oval
Plateau ovale
29,5 x 21 cm x H 2,5 cm



1204_10_010

22.50



Fischplatte oval
Plat à poisson ovale
32 x 24 cm x H 3,4 cm



1205_10_010

29.80

Platte oval
Plat ovale
38 x 19 cm x H 3,6 cm



1206_10_010

42.50

Platte oval
Plat ovale
46 x 22,5 cm x H 5,5 cm



1207_10_010

57.00



Coupeteller rechteckig
Assiette coupe rectangulaire
27 x 16 cm x H 3 cm



1301_10_010

18.50

Passend/compatible 5301_10_010

Schale rechteckig
Bol rectangulaire
27 x 16 cm x H 5,2 cm / 110 cl



2301_10_010

24.50

Passend/compatible 5301_10_010

Cloche rechteckig
Cloche rectangulaire
28 x 17 cm x H 6 cm



5301_10_010

24.50



Dessertschale konisch
Bol conique
Ø 15 cm x H 5,0 cm / 29 cl

2103_10_010

9.95



Müslischale konisch
Bol conique
Ø 17 cm x H 6,5 cm / 50 cl

2104_10_010

10.80



Schälchen konisch
Bol conique
Ø 21 cm x H 6 cm / 82 cl

2105_10_010

15.80



Schale konisch
Bol conique
Ø 26 cm x H 11 cm / 222 cl

2107_10_010

21.50



Schale konisch
Bol conique
Ø 20 cm x H 14 cm / 155 cl

2108_10_010

14.50



Dip Schälchen
Coupelle dip
Ø 8 cm x H 4 cm / 6 cl

2109_10_010

6.95



Schale Bol
Ø 12 cm x H 6,2 cm / 40 cl

2102_10_010

9.50



Schale Bol
Ø 19 cm x H 5,5 cm / 90 cl

2110_10_010

12.95

Passend/compatible 5107_10_010



Schale oval
Bol ovale
17 x 12 cm x H 7,5 cm / 65 cl

2201_10_010

12.50



Schälchen quadratisch
Coupelle carrée
8,5 x 8,5 cm x H 6,5 cm / 21 cl

2401_10_010

8.50



Espressotasse
Tasse à espresso
H 4,8 cm / 6 cl



3107_10_010 6.95
Passend/compatible 3121_10_010

Espressotasse
Tasse à espresso
H 5,7 cm / 9 cl



3101_10_010 6.95
Passend/compatible 3121_10_010

Kaffeetasse
Tasse à café
H 6,2 cm / 19 cl



3104_10_010 7.95
Passend/compatible 3123_10_010

Kaffeetasse
Tasse à café
H 8,2 cm / 31 cl



3105_10_010 8.50
Passend/compatible 3123_10_010



Teetasse
Tasse à thé
H 7,5 cm / 30 cl



3103_10_010 9.95
Passend/compatible 3122_10_010

Becher mit Henkel
Gobelet avec anse
H 12 cm / 40 cl



3106_10_010 9.75
Passend/compatible 3122_10_010

Consommé Tasse
Tasse à consommé
H 7,5 cm / 39 cl



3102_10_010 11.95
Passend/compatible 3122_10_010



Untertasse
Soutasse
Ø 11 cm x H 2 cm



3121_10_010 4.80

Untertasse
Soutasse
Ø 15,5 cm x H 2,5 cm



3123_10_010 5.95

Untertasse
Soutasse
Ø 16,5 cm x H 2,4 cm



3122_10_010 6.95



Kaffeekanne/Teekanne
Cafetière/Théière
H 12 cm / 72 cl



4102_10_010

55.00



Kaffeekanne/Teekanne
Cafetière/Théière
H 13,5 cm / 110 cl



4101_10_010

59.00



Zuckerdose mit Deckel
Sucrier avec couvercle
Ø 11 cm x H 11 cm / 32 cl



5109_10_010

17.50



Schälchen mit Deckel
Bol avec couvercle
Ø 11,5 cm x H 6,1 cm



2101_10_910

12.85



Giesser
Cremier
H 6 cm / 6 cl



4103_10_010

13.50



Giesser
Cremier
H 7,5 cm / 15 cl



4104_10_010

15.80



Giesser
Cremier
H 13 cm / 50 cl



4105_10_010

19.80



Eierbecher
Coquetier
Ø 11 cm x H 2,5 cm



5101_10_010

10.80



Pfefferstreuer
Poivrier
Ø 5 cm x H 7 cm
 

5102_10_010

8.50

Salzstreuer
Salière
Ø 5 cm x H 7 cm
 

5103_10_010

8.50

Kerzenständer
Bougeoir
Ø 8 cm x H 4 cm
 

5104_10_010

17.80

Teelicht
Photophore
Ø 10,5 cm x H 6,2 cm
 

5106_10_010

19.80



Vase
Vase
Ø 9 cm x H 14 cm
 

5105_10_010

18.95

Centerpiece
Pièce maîtresse
Ø 35 cm x H 16 cm
 

5108_10_010

69.00

Terrine
Terrine
H 20 cm / 250 cl
 

5111_10_010

79.00

